



RCDK7M/C Assembly Instructions

DESIGNED IN AUSTRALIA BY:
THOMAS MOLONEY PTY LTD.
PH 02 4340 1444 FAX 02 4340 1400
EMAIL enquiry@rolacase.com
www.rolacase.com

Instructions:

Supplied:

1x handle
4x 6mm x 12mm long screws
2x fixed castors
2x swivel castors
16x 8mm nyloc nuts

Required for Assembly (Not Supplied)

Phillips screwdriver
13mm spanner or socket

Procedure:

- 1/. Insert the Handle in the 2 slots on the top of the trolley and secure in place with the 4x 6mm screws supplied
- 2/. Mount the 2 fixed wheels on the 8mm studs under the trolley (opposite end to the handle) and secure with 4x 8mm nyloc nuts for each castor.
- 3/. Mount the 2 swivel wheels on the 8mm studs under the trolley (handle end) and secure with 4x 8mm nyloc nuts for each castor.

