

# ROLA·CASE ROLA·Shelf

## MULTIPLE STORAGE SYSTEMS

**Step 1-** Remove tie down points and any trim that may interfere with the floor. Remove any existing flooring (i.e. Plastic flooring) and rubber mats.

**Step 2-** Place packers to help support the floor in low spots if required but not necessary

**Step 3-** Secure packers to the flooring piece using screws provided (for applicable for Hyundai Iload)



**Step 4-** Lay floor in place. Will be neat due to computer cut

**Step 5 -** Loosely replace tie down points & bolts so the floor can be readjusted if required



**Step 6-** Fit tongue & groove - by sliding metal strip in the slot where 2 pieces of floor join

**Step 7-** Secure tie down points and bolts. Place trim in position and secure by screwing in place



Any queries give us a call on  
**(02) 43401444**